

SERVICE INSTRUCTION

AEROBELL™ MOUNTING HARDWARE

<i>Aerobell Mounting Hardware</i>			
Mounting Assy. #	Description	Type of Application	Figure #
RPM-433	Mounting Bracket Assembly	Aerobell Extended Shroud	1
RPM-434	Support and Tube Assembly	Aerobell W/ARCBAR Power Supply	2
RPM-436	Mounting Bracket and Clamp Assembly	Aerobell W/Charged Gun Mounting Post	3




Figure 1: RPM-433 Mounting Bracket Assembly




Figure 2: RPM-434 Support and Tube Assembly




Figure 3: RPM-436 Mounting Bracket and Clamp Assembly

Manufacturing

1910 North Wayne Street
Angola, Indiana 46703-9100
Telephone: 260/665-8800
Fax: 260/665-8516
www.itwransburg.com

Technical / Service Assistance

Telephone: 800/ 626-3565 Fax: 419/ 470-2040
Telephone: 800/ 233-3366 Fax: 419/ 470-2071

Technical Support Representative will direct you to the appropriate telephone number for ordering Spare Parts.